

Installation Guide


Remote Control Unit

PVRES





155R9950



155R9950




 155B167.10	Standard version	155B4210
	Short version	155B4209 155B4218







 155B168.10	Standard version	155B4211
	With spareparts	155B4217






 155B169.10	Standard version	155B4212 155B4504
	Short version	155B4219 155B4505









E	Nødstop Emergency stop Notschalter Arrêt d'urgence
T	Fladstik A 6,3 - 0,8* Tabs A 6,3 - 0,8* Flachstecker A 6,3 - 0,8* Languettes mâles A 6,3 - 0,8*

*(DIN 46244)



Plombering af justerknapper
Sealing of adjusting knobs
Siegeln von Stellknöpfen
Plombage des boutons d'ajustage



155B309.10