
 Spare part list	Valve type RS 210	Coordinat DB
	Created 2011-11-21	

LE11



Part No	Description
2160-266208	Spool control, position indicator
2230-266227	Sparepart kit 1 consisting of position 2, 3, 5
2230-266238	Sparepart kit 2 consisting of position 2, 3, 4, 5
2230-266228	Sparepart kit 3 consisting of position 1, 2, 3, 4, 5, 6, 9
2230-266221	Sparepart kit 4 consisting of position 1 to 9

Notes: