




High pressure carry-over

High pressure carry-over plug PS28

Plug PS28, mounted in S1 allows carry-over function.



Typical hydraulic circuit diagrams

Diagram 1: High pressure carry-over




Diagram 2: Two pump circuit with intermediate section (K3)

