



Model:185K
Chapter 2 Base

4949722
Operating assembly 5/6F & Stab. (Page1/2)

4949722 - Operating assembly 5/6F & Stab. (Page1/2)		Pos	Part No	Description	Quantity
494-9722B Page 1/2 See page 2/2 		1	9821449	ANGLE COUPLING	3
		2	9985387	ANGLE COUPLING	2
		4	9819975	ANGLE COUPLING	4
		5	9821767	ANGLE COUPLING	1
		6	9818219	ANGLE COUPLING	1
		7	9821104	ANGLE NIPPLE	1
		9	9924205	SCREW	1
		10	9924131	SCREW	3
		13	3015742	CLAMP	2
		21	3942678	CONTROL VALVE 4 FUNCTION	1
		22	9809945	HANDLE (BLACK)	9
		23	9819851	HANDLE (RED)	1
		26	9819894	HP HOSE	2
		27	3631290	HYDR. PIPE	1
		28	1864106	HYDR. PIPE	1
		29	3037878	LEVER	6
		33	9824529	ANGLE COUPLING	1
		35	9800671	NUT	1
		39	3596087	PLATE	1
		41	9991671	REDUCTION NIPPLE	1
		48	9998438	COUPLING	4
		51	9819771	T-COUPLING	1

Model:185K**Chapter 2 Operating assembly 5/6F & Stab. (Page1/2)****4949723****Operating assembly 5/6F & Stab. (Page 2/2)**

4949723 - Operating assembly 5/6F & Stab. (Page 2/2)		Pos	Part No	Description	Quantity
		8	9924205	SCREW	4
		11	3585000	BRACKET	1
		12	3615804	BRACKET	1
		14	3569543	CONTROL ROD	2
		15	3552527	SYMBOL SIGN	1
		16	3552535	SYMBOL SIGN	1
		17	3552543	SYMBOL SIGN	1
		18	3552560	SYMBOL SIGN	1
		19	3552578	SYMBOL SIGN	1
		20	3552586	SYMBOL SIGN	1
		24	3002985	SPACING RING	3
		25	9809996	FORK	2
		30	3518540	LEVER	2
		31	3421198	LEVER	2
		32	3544851	LINK	2
		34	9900047	NUT	2
		36	3010767	BOLT	8
		37	9952217	SHAFT	2
		38	3905853	BOLT	2
		40	9965823	LOCKING NUT	4
		42	9950711	RETAINING RING	1
		43	9810005	SECURING PLATE	2
		44	9949305	LOCK WASHER	10
		46	3476162	SPACER	2
		47	9904131	SPRING WASHER	4
		49	9104569	CONTROL SIGN	2
		50	3596117	SIGN	2