


Model:085
Chapter 9 SPACE components (Page 1/2)

49177402
SPACE components on base (Page 2/2)

491-7740 page 2
SPACE COMPONENTS
on BASE

See page 1



PSBM

24 V MAINPOWER

ASBM

HP-INTERFACE

DUMP-VALVE

TO COLUMN BOX

SPACE

SPOOL SENSORS

Pos	Part No	Description	Quantity
1	3630617	CABLE 2X1.5mm2 LG.5000	1
2	9827242	CONDUIT ENTRY PG 9	6
3	9921265	O-RING	6
4	9828010	CABLE SWIVEL NUT PG 9	1
5	3623017	CONNECTION BOX	1
6	8146594	CABLE 6X0.75mm2 LG.2100	1
7	3623157	CONNECTION BOX	1
8	4471270	CABLE 6X0.75mm2 LG.1400	1
9	3600700	ELECTRONIC BOX(SPACE)	1
10	9827269	CONDUIT ENTRY PG 13.5	1
11	9921290	O-RING	1
12	3657051	SPOOL POSITION SENSOR	2
14	3629201	CABLE 4X0.75mm2 LG.500	1
15	4460359	CABLE 2X0.75mm2 LG.2000	1

SPACE components on base (Page 2/2) - 49177402