


Model:106 HD Chapter 4 Boom system

10608 Boom extension

10608 - Boom extension



Pos	Part No	Description	Quantity
1	3603610	EXTENSION	1
2	3603300	SLIDE PAD	2
3	3603563	SHIM	1
4	3555721	STOP	1
5	9900462	SCREW	2
6	9817115	LOCK NUT	6
7	3603377	SHAFT	1
8	3527077	BRACKET	2
9	9991026	SCREW	4
10	3614301	SHAFT	1
11	9949623	WASHER	1
12	9965513	NUT	1
13	9903429	SPLIT PIN	1