


Model:14627
Chapter

Serial number 14627

3112301
3112301 Second boom

3112301 - 3112301 Second boom		Pos	Part nr	Description	Quantity
		1	94282400	Second boom	1
		2	94566321	Shaft	1
		3	94242339	Set screw	1
		4	9978119	LOCKING NUT	1
		5	94259433	Second boom cylinder cover	1
		6	94259434	Second boom cylinder cover	1
		7	94259435	Bail	2
		8	94259421	FLANGE	2
		9	94259425	Slide pad	8
		10	45634059	Hexagon set screw	12
		11	41264080	Hexagon screw	14
		12	54201210	Lock washer	34
		13	67411010	Grease nipple	2
		14	3558967	SHIM	1
		15	3551679	PLATE	1
		16	94275628	Spanner	2
		17	94275627	Adjusting screw	2
		18	94275631	Bushing	2
		19	94275625	Slide pad	2
		20	3603407	SLIDE PAD	1
		21	3589706	NUT	2
		22	45635089	Hexagon set screw	4
		23	54201212	Catch	4
		24	41264120	Hexagon screw	8
		25	94432510	Shaft	1
		26	41266080	Hexagon screw	6
		27	54330250	Circlip	2
		28	94282416	Grapple console	1
		29	54200163	Spring washer	6
		30	94259229	Distance ring	1
		51	3350371	SLEEVE	0
		52	94263938	Guide sleeve	0
		311.230.1 Second boom 1 No 145001-, 14601-			0


3112301_1

Model:14627
Chapter

Serial number 14627

3112401
3112401 Extension

3112401 - 3112401 Extension



3112401_1

Pos	Part nr	Description	Quantity
1	94282500	Extension	1
2	94282550	Shaft	1
3	54330250	Circlip	2
4	3603300	Slide piece	2
5	94282518	Adapter plate	1
6	94282519	Stopper	1
7	94241667	Shaft	1
8	54060333	Washer	1
9	47990300	Hexagon slotted nut	1
10	54743300	Split pin	1
11	41264080	Hexagon screw	2
12	54200103	Spring washer	2
13	48115230	Hexagon set screw	2
14	46332120	Hexagon nut	2