


Model:J 1020
1042001
Base, L=1132

1042001 - Base, L=1132



1042001 - Base, L=1132

Pos	Part No	Description EN	Description DE	Quantity
0	104.200.1	Base 2 No 11101-		0
1	3611451	Base	Grundgestell	1
2	3546837	Bearing bush	Lagerbuchse	1
3	3546829	Bearing bush	Lagerbuchse	1
4	3546845	Axial ball bearing	Axiallager	1
5	9982931	Seal	Dichtung	1
6	38100645	Plug	Pfropfen	3
7	3611469	Oil dipstick	Ölstandmesser	1
8	67411010	Grease nipple	Schmiernippel	3
9	9967010	Hexagon nut	Sechskantmutter	6
10	3704831	Stud	Stiftschraube	6
11	3702758	Fastening tile	Befestigungsplatte	2
12	9921338	O-ring	O-Ring	2
13	3419827	Stopping piece	Anschlag	2
14	3493555	Locking plate	Verriegelungsblech	2
15	41264080	Hexagon screw	Sechskantschraube	4
16	3604314	Bushing	Buchse	1
17	3546853	Seal	Dichtung	1
18	82371821	Seal ring	Dichtungsring	1
19	30679408	Plug	Pfropfen	1
20	41263610	Hexagon screw	Sechskantschraube	6
21	3705226	Navel	Nabel	1
22	82368700	O-ring	O-Ring	2
23	3704904	Fastening balk assy	Befestigungsbalken komplett	1
24	9851704	Bearing bush	Lagerbuchse	0
25	3705234	Deck	Deckel	1
26	3097889	Washer	Unterlagscheibe	4
27	9923136	Socket head cap screw	Innensechskantschraube	4
28	82371827	Seal ring	Dichtungsring	3
29	82371810	Seal ring	Dichtungsring	2
51	104110	Fastening balk	Befestigungsbalken	0
Kit 104105		Base assy	Grundgestell komplett	
1	3611451	Base	Grundgestell	1
2	3546837	Bearing bush	Lagerbuchse	1
3	3546829	Bearing bush	Lagerbuchse	1
4	3546845	Axial ball bearing	Axiallager	1
5	9982931	Seal	Dichtung	1
6	38100645	Plug	Pfropfen	3
7	3611469	Oil dipstick	Ölstandmesser	1
8	67411010	Grease nipple	Schmiernippel	3
16	3604314	Bushing	Buchse	1
17	3546853	Seal	Dichtung	1
18	82371821	Seal ring	Dichtungsring	1
19	30679408	Plug	Pfropfen	1
20	41263610	Hexagon screw	Sechskantschraube	6
28	82371827	Seal ring	Dichtungsring	3