


Model:022T Penman Chapter 4 Boom system

520454

1st boom 022T-2 cpl. (Page 1/2)

520454 - 1st boom 022T-2 cpl. (Page 1/2)



Pos	Part nr	Description	Quantity
1	523461	FIRST BOOM	1
2	523275	EXTENSION	1
6	3197336	CLAMP	4
7	153613	SCREW	2
8	534692	LOCKING WASHER	2
9	525065	SHAFT	2
10	534757	LOCKING WASHER	2
11	159204	PIN	4
12	9962824	SCREW	6
13	9903861	WASHER	6
14	9900390	SCREW	6
15	576000	SHIM	3
16	575003	STOP	3
17	526371	SLIDE PAD	2
18	536806	SHIM	2
19	556831	SLIDE PAD	2
20	548421	SHIM	2
21	153346	SCREW	4
22	157473	NUT	4
25	150630	BALL	2
26	575429	LOCKING PIN	2
36	526371	SLIDE PAD	2
37	536806	SHIM	2
15A	576018	SHIM	3
16A	575038	STOP	3
18A	536814	SHIM	2
19A	535133	SLIDE PAD	2
37A	536814	SHIM	2

1st boom 022T-2 cpl. (Page 1/2) - 520454


Model:022T Penman

Chapter 4 1st boom 022T-2 cpl. (Page 1/2)

520454.2

1st boom 022T-2 cpl. (Page 2/2)

520454.2 - 1st boom 022T-2 cpl. (Page 2/2)




520780
520454
Page 2/2

See page 1/2

Pos	Part nr	Description	Quantity
3	523283	EXTENSION	1
4	523291	EXTENSION	1
23	556823	SLIDE PAD	2
24	548464	SHIM	2
25	150630	BALL	2
26	575429	LOCKING PIN	2
29	9903356	COTTER PIN	1
30	156469	WASHER	2
31	475181	BUSHING	1
32	525189	SHAFT	1
33	159751	COTTER PIN	1
34	107638	LOAD HOOK	1
35	191892	CATCH	1
38	526380	SLIDE PAD	2
39	526347	SHIM	2
23A	574910	SLIDE PAD	2

1st boom 022T-2 cpl. (Page 2/2) - 520454.2

535516 - Hook bracket				Pos	Part nr	Description	Quantity
				1	535516	BRACKET HOOK	1
				2	156418	WASHER	1

Hook bracket - 535516