


1082001 - Base



1082001 - Base

Pos	Part No	Description EN	Description DE	Quantity
1	94562100	Base	Grundgestell	1
2	94562101	Bearing	Lager	1
3	94238235	Flange	Flansch	1
4	94238206	Flange	Flansch	1
5	60410340	Spherical roller bearing	Kugelrollen	1
6	94383030	Oil level eye	Ölstandauge	2
7	30676040	Plug	Pfropfen	2
8	82369040	O-ring	O-Ring	1
9	82369046	O-ring	O-Ring	1
10	38100645	Plug	Pfropfen	2
11	30679319	Plug	Pfropfen	2
12	82371833	Seal ring	Dichtungsring	2
13	82371827	Seal ring	Dichtungsring	2
14	67411011	Grease nipple	Schmiernippel	2
15	94380726	Coupling, swing elbow	Schwenkverschraubung	1
16	94238931	Pipe	Rohr	1
17	45634109	Socket head cap screw	Innensechskantschraube	6
18	45625149	Socket head cap screw	Innensechskantschraube	16
19	54020012	Washer	Unterlagscheibe	16
20	41264050	Hexagon screw	Sechskantschraube	8
21	54201210	Lock washer	Fächerscheibe	8
50	94562112	Base assy	Grundgestell komplett	0
	1082001	Base 1 No 25301-		0