




Fig.	Cant Qty. Qte.	Nº código Order.nr Nº code	Descripción	Description	Description	Notas Notes Notes
1	4	996 4347	Tuerca autobloc.	Lock nut	Ecrou autobloc.	Double Basic Double Basic
2	1	990 4140	Arandela muelle	Spring washer	Rondelle ressort	
3	2	531 9862	Casquillo	Bushing	Bague	
-	2	831 2508	Casquillo	Bushing	Bague	
4	1	531 9820	Bulón	Shaft	Boulon	
-	1	831 2494	Bulón	Shaft	Boulon	
5	1	894 0134	Arandela	Washer	Rondelle	
6	1	992 4205	Tornillo	Screw	Vis	
7	1	831 2401	Tuerca	Nut	Ecrou	
8	1	891 2629	Tuerca	Nut	Ecrou	
9	2	342 5878	Tope	Stop	Arrêt	Double Basic Double/valv.
10	2	992 4001	Tornillo	Screw	Vis	
11	2	992 9410	Tuerca autobloc.	Lock nut	Ecrou autobloc.	
12	1	532 9256	Extensión 2	Extension 2	Extension 2	
13	2	839 6752	Tornillo	Screw	Vis	
14	2	831 2397	Placa deslizamiento	Slide pad	Glissière	
15	4	897 6155	Placa deslizamiento	Slide pad	Glissière	
16	2	871 4207	Tornillo	Screw	Vis	
17	2	898 2066	Arandela	Washer	Rondelle	
18	2	835 1783	Placa deslizamiento	Slide pad	Glissière	
19	2	990 4131	Arandela muelle	Spring washer	Rondelle ressort	Double Basic Double/valv.
20	1	831 2001	Placa deslizamiento	Slide pad	Glissière	
21	2	831 2125	Placa	Plate	Plaque	
22	1	831 2028	Placa deslizamiento	Slide pad	Glissière	
23	2	831 2133	Placa	Plate	Plaque	
24	2	831 2427	Tope	Stop	Arrêt	
25	2	831 1871	Placa deslizamiento	Slide pad	Glissière	
26	4	831 1943	Placa	Plate	Plaque	
27	4	997 7414	Tornillo	Screw	Vis	
28	2	992 5244	Abrazadera	Hose clamp	Collier de serrage	
29	2	891 6985	Protección	Protection	Protecteur	Double Basic Double/valv.
30	1	998 5379	Racor codo	Elbow nipple	Raccord	
31	4	995 3523	Tuerca	Nut	Ecrou	
32	4	835 4685	Tornillo	Screw	Vis	
33	1	532 3797	Tubo	Pipe	Tube	
-	1	825 3026	Tubo	Pipe	Tube	
-	1	835 3026	Tubo	Pipe	Tube	
34	4	894 7678	Suplemento	Spacer	Separateur	