




**JONSERED**FOT
BASE
FUSS

2190

1
9002

2

Pos Fig. Teil	Ant Qty Anz	Best.nr Order.nr Best.nr	Benämning	Description	Benennung	Anm. Notes Anm.
-						355 5551-J313 356 0431-LC
1	10	990 0527	Skruv	Screw	Schraube	
2	2	990 6185	Smörjnippel	Grease nipple	Schmiernippel	
3	1	354 2572	Hållare	Holder	Halter	
4	1	981 6801	O-ring	O-ring	O-ring	
5	1	992 1681	O-ring	O-ring	O-ring	
6	1	981 7093	Rullager	Roller bearing	Rollenlager	
7	1	354 2581	Svänghus	Slewing housing	Schwenkgehäuse	
8	4	711 8200	Svängcylinder	Slewing cylinder	Schwenkzylinder	
9	48	992 2661	Skruv	Screw	Schraube	
10	58	994 9615	Bricka	Washer	Scheibe	
11	4	993 3522	O-ring	O-ring	O-ring	
12	4	996 0791	Tättring	Seal ring	Dichtungsring	
13	2	711 3043	Kuggstång	Rack	Zahnstange	
14	1	981 7107	Rullager	Roller bearing	Rollenlager	
15	1	980 9015	Axiallager	Bearing	Achsiialager	
16	2	980 9023	Bricka	Washer	Scheibe	
17	1	992 1541	O-ring	O-ring	O-ring	
18	1	354 2602	Lagerhus	Bearing housing	Lagergehäuse	
19	1	351 5877	Hylsa	Sleeve	Hülse	
20	1	351 5885	Skruv	Screw	Schraube	
21	1	991 0450	O-ring	O-ring	O-ring	
22	1	731 6747	Lock	Cover	Deckel	
23	2	992 4213	Skruv	Screw	Schraube	
24	2	990 4140	Bricka	Washer	Scheibe	
25	1	997 3818	Skruv	Screw	Schraube	
26	1	993 9415	Bricka	Washer	Scheibe	
27	1	351 5893	Bricka	Washer	Scheibe	
28	10	991 0638	Skruv	Screw	Schraube	
29	4	351 3190	Tättningsbricka	Seal washer	Dichtungsscheibe	
30	4	992 4469	Skruv	Screw	Schraube	
31	2	355 5542	Glidklack	Slide pad	Gleitklotz	
32	1	998 8092	Nippel	Nipple	Nippel	
33	1	995 0940	*O-ring	*O-ring	*O-ring	
34	1	981 9142	*Stödring	*Support ring	*Stützring	
35	1	998 5352	Koppling	Coupling	Kupplung	
36	1	995 0940	*O-ring	*O-ring	*O-ring	
37	1	981 9142	*Stödring	*Support ring	*Stützring	
38	1	998 2191	Avstängningsventil	Shut-off valve	Absperrventil	
39	1	990 3631	Propp	Plug	Pfropfen	
40	1	998 4186	Nivåglas	Level gauge	Niveau-schauglas	
41	1	998 7363	*Tättring	*Seal ring	*Dichtungsring	
42	1	990 3658	Propp	Plug	Pfropfen	
43	1	998 3694	Ljuddämpare	Silencer	Schalldämpfer	