



NOTES

- Install back-up rings and O-rings as shown in views.
- When installing continuous back-up rings, use the same technique and the same care used to install O-rings.
- When installing cartridge - be sure to torque to recommended value.

USED WITH

DSFD	DSGH	DSGO	DSGS	DSGX	DSGY	FSEA	FSEC	FSED	FSEG
FSEH	FSER	FSES	LHHA	LHHT	XTCA				