



No.	Spare part	Qty.	Description	Dimension
1	J103T01-C	1	Boom extension-1	224x122 mm
2	HF 575A	2	Guide	2 mm
2	HF 576A	2	Guide	4 mm
2	HF 577A	2	Guide	5 mm
2	HF 578A	2	Guide	6 mm
2	HF 608A	2	Guide	1,5 mm
2	HF 727A	2	Guide	7 mm
2	HIA 130A	2	Guide	3 mm
3	HF1385A+00008	2	Guide block	8 mm
3	HF1385A+00009	2	Guide block	9 mm
3	HF1385A+00010	2	Guide block	10 mm
3	HF1385A+00011	2	Guide block	11 mm
3	HF1385A+00012	2	Guide block	12 mm
3	HF1385A+00013	2	Guide block	13 mm
3	HF1385A+00014	2	Guide block	14 mm
3	HF1385A+00015	2	Guide block	15 mm
4	HXE1853A	1	Cylinder guide	
	ES 297	2	Screw	M 8x25 ISO14581- 8.8
	EZ2758	1	Guide block	
	HA8001	1	Bearer	
5	ES 308	2	Screw	M 8x20 DIN7984- 8.8
6	EK 003	4	Washer	D 8.4 ISO7089
7	HBS7789	2	Bushing	
8	UP1854B	1	Extension boom ram see page 0700.01001-A	Cr
9	ES1163	1	Screw	M 8x110 DIN 912
10	HT1040	1	Bearer	L0042.0xB0019.0xS006
11	EF 144	1	Spring	
12	EM 026	1	Nut	DIN 985 M 8
13	HTR2951A	2	Guide block	6 mm
13	HTR2952A	2	Guide block	8 mm
13	HTR2953A	2	Guide block	10 mm
13	HTR2982	2	Guide block	1 mm
13	HTR3331A	2	Guide block	7 mm
13	HTR3667A	2	Guide block	9 mm
13	HTR4125A	2	Guide block	5 mm
13	HTR4127	2	Guide block	0.5 mm
13	HTR4280A	2	Guide block	12 mm
14	HF1380A+00008	2	Guide block	8 mm
14	HF1380A+00009	2	Guide block	9 mm
14	HF1380A+00010	2	Guide block	10 mm
14	HF1380A+00011	2	Guide block	11 mm
14	HF1380A+00012	2	Guide block	12 mm
14	HF1380A+00013	2	Guide block	13 mm
14	HF1380A+00014	2	Guide block	14 mm
15	ES1089	4	Screw	M 8x10 DIN 7984 8.8
15	ES1082	4	Screw	M 8x12 DIN 7984 8.8
16	EV4707-330 -->100168829	1	Load holding valve	
	TD1600	1	Seal kit	
16	EV5886-330 100168830-->	1	Load holding valve	
	EV5891	1	Solenoid valve	
17	EZ1438	2	Sealing cap	
18	HBS1073A	2	Spacer	l=33 mm

Extension boom 1 + piping

No.	Spare part	Qty.	Description	Dimension
19	ES1370	2	Screw	M 8x75 DIN 912
20	EA 183	2	Fitting	GE 12S R1/2"-ED
21	HLR12089	1	Pipe	D 12
22	HLR12090	1	Pipe	D 12
23	EA1749	2	Adaptor	WH 12S 3/8"