

No.	Spare part	Qty.	Description	Dimension
1	HXE4270	1	Cover	
2	ES2566	3	Screw	M 08x10 ISO7380MF
3	ES 031	2	Screw	M 10x30 ISO4762-10.9
4	UP2863	1	Tilt cylinder see page 0100.12402-B	
5	HT10809	1	Rack	
6	ES 298	1	Screw	M 10x20 ISO14581- 8.8
7	EA 005	1	Grease nipple	M10x1 DIN71412
8	ES 587	5	Screw	M 10x25 DIN7984
9	HXE4289	1	Bracket	
10	HF1816	1	Guide block	
11	ES 844	2	Screw	M 12x45 DIN 931
12	HT10808	1	Gear wheel	
13	ES 227	1	Screw	M 12x30 DIN7991
14	HXE4258	1	Fastening plate	
15	EF 144	1	Spring	
16	HT1040	1	Bearer	L=42 B=19 S=6
17	UP2865	1	Stabilizer ram see page 0100.12401-A	l=1059 mm
18	HXE4261	1	Stabilizer support	
19	EK1064	1	Stop buffer	30x30 mm
20	EM 086	1	Nut	M 12 DIN 936
21	ES1273	1	Screw	M 12x30 DIN 933
22	EK 148	8	Washer	D 14 DIN 134
23	EK 588	2	Washer	D 14
24	ES 415	10	Screw	M 14x30 DIN 933

