





Pos Fig Teil	Ant Qty Anz	Best.nr Order.nr Best.nr	Benämning	Description	Benennung	Anm. Notes Anm.
1	1	359 7369	Stödbensbalk	Outrigger beam	Stützbeinbalken	See page 13
2	2	359 7377	Utdragsbalk	Extension beam	Ausziehteil	
3	1		Hydraulcylinder	Hydraulic Cylinder	Hydraulikzylinder	
4	16	354 9119	Glidklack	Slide pad	Gleitklotz	
5	24	359 7598	Schims	Shim	Schims	
6	2	354 9135	Axel	Shaft	Achse	
7	4	990 7602	Bricka	Washer	Scheibe	
8	4	990 5898	Spårring	Retaining ring	Nutring	
9	2	355 7944	Skydd	Guard	Schütz	
10	4	992 4205	Skruv	Screw	Schraube	
11	1	359 7296	Svänghus	Slewing housing	Schwenkgehäuse	
12	1	347 7771	*Bussning	*Bushing	*Buchse	
13	1	982 0043	*Spårring	*Retaining ring	*Nutring	
14	1	354 6845	Axiallager	Bearing	Achsiallager	
15	1	982 6823	Rullager	Roller bearing	Rollenlager	
16	1	982 6815	Tätningssring	Seal ring	Dichtungsring	
17	1	991 2363	O-ring	O-ring	O-ring	
18	1	359 7342	Lock	Cover	Deckel	
19	6	990 0471	Skruv	Screw	Schraube	
20	1	350 7840	Tapp	Pin	Zapfen	
21	1	996 2832	Tätningssbricka	Seal washer	Dichtungsscheibe	
22	1	990 8510	Skruv	Screw	Schraube	
23	2	390 0665	Propp	Plug	Pfropfen	
24	1	995 0940	*O-ring	*O-ring	*O-ring	
25	2	349 3539	Glidklack	Slide pad	Gleitklotz	
26	2	349 3547	Styrklack	Guide	Führungsstück	
27	2	992 1389	O-ring	O-ring	O-ring	
28	2	990 0497	Skruv	Screw	Schraube	
29	2	354 9143	Svängkolv	Slewing piston	Schwenkkolben	
30	4	711 6672	Tättring	Seal ring	Dichtungsring	
31	4	993 3476	O-ring	O-ring	O-ring	
32	16	991 0565	Bricka	Washer	Scheibe	
33	16	992 3047	Skruv	Screw	Schraube	
34	4	354 5075	Svängcylinder	Slewing cylinder	Schwenkzylinder	
35	2	360 4357	Konsol	Bracket	Konsole	
36	4	992 4213	Skruv	Screw	Schraube	
37	6	996 7010	Mutter	Nut	Mutter	
38	6	360 9855	Pinnskruv	Stud bolt	Stiftschraube	
39	6	350 9206	Tapp	Pin	Zapfen	
40	1	360 4179	Stöd	Support	Stütze	
41	8	981 7123	Låsbricka	Locking washer	Sicherungsscheibe	
42	4	992 4621	Skruv	Screw	Schraube	
43	2	992 4191	Skruv	Screw	Schraube	
44	1	360 4381	Fästplåt	Fixing plate	Befestigungsblech	
45	1	360 4411	Filterhållare	Filter support	Filterhalter	
46	1	360 4161	Stöd	Support	Stütze	
47	2	359 7652	Klack	Dog	Anschlag	
48	2	360 3679	Schims	Shim	Schims	
49	4	992 4337	Skruv	Screw	Schraube	
50	1	359 7351	Nivåskala	Level scale	Niveau-skala	



**JONSERED****FOT MED SVÄNGSYSTEM
BASE, SLEWING SYSTEM
FUSS, SCHWENKSYSTEM****890****2****9409****2**

Pos Fig Teil	Ant Qty Anz	Best.nr Order.nr Best.nr	Benämning	Description	Benennung	Anm. Notes Anm.
51	4	992 4434	Skruv	Screw	Schraube	
52	4	991 4129				
53	4	995 3523	Låsmutter	Locking Nut	Gegenmutter	
54	1	359 7318	Tapp	Pin	Zapfen	
55	4	992 3101	Skruv	Screw	Schraube	
56	3	990 6185	Smörjnippel	Grease nipple	Schmiernippel	
57	1	354 9046	Ledbrygga	Three point bridge	Gelenkbrücke	
58	1	354 9071	*Bussning	*Bushing	*Buchse	
59	4	992 4205	Skruv	Screw	Schraube	
60	2	359 7334	Stopp	Stop	Anschlag	
61	2	993 3395	O-ring	O-ring	O-ring	
62	1	990 9206	Spårring	Retaining ring	Nutring	