




05/2003

Nr. No. No.	Ersatzteil Nr. Sparepart no. No Piece de rechange	Stk. Qty. Nbre.	Teilebezeichnung	Description	Nomenclature	Abmessung Dimension Dimension
51	BK010	2	Laufrolle	<i>Tread roller</i>	Galet de roulement	
52	E75015	2	O-Ring	<i>O-ring</i>	Joint torique	D=12 d=2
53	E50031	2	Sechskantschraube	<i>Screw</i>	Vis	M30x190x40 DIN931
54	E50005	4	Zylinderschraube	<i>Cheese head screw</i>	Vise tete cylindr.	M12x30 DIN912 8.8
55	BV001	2	Rückschlagventil	<i>Check valve</i>	Soupape de retenue	
56	E50020	8	Sechskantschraube	<i>Screw</i>	Vis	M12x30 DIN933 10.9
57	E71030	2	Leitung	<i>Pipe</i>	Tuyau	12x1,5
58	E72003	2	Schlauch	<i>Hose</i>	Flexible	3/8"-1300- I12L- A12L
59	E50013	4	Zylinderschraube	<i>Cheese head screw</i>	Vise tete cylindr.	M8x55 DIN912 8.8
60	E50030	2	Sechskantschraube	<i>Screw</i>	Vis	M12x130 DIN931 8.8
61	E17017	2	Stützteller	<i>Stabilizer plate</i>	Plaque de stab.	
62	E50012	8	Sechskantschraube	<i>Screw</i>	Vis	M10x20 DIN933 8.8
63	E01011	2	Stützzyylinder	<i>Stabilizer ram</i>	Verin de stabilisat	
	BD012	2	Dichtungssatz	<i>Seal kit</i>	Pochette de joints	
64	E52001	1	Mutter	<i>Nut</i>	Ecrou	M12 DIN985-8
65	E70007	6	Verschraubung	<i>Adaptor</i>	Raccord	SV 12L
66	E70008	2	Verschraubung	<i>Adaptor</i>	Raccord	EL 12L
67	E72020	1	Schlauch	<i>Hose</i>	Flexible	5/8"-800-A18L-A18L
68	BL006	1	Leitungsbausatz	<i>Pipe kit</i>	Emsemble de tuyautiers	
69	E58011	8	Handgriff	<i>Handle</i>	Poignee	
70	E16027	6	Handhebel	<i>Hand lever</i>	Levier a main	
71	E53005	24	Sicherungsscheibe	<i>Locking washer</i>	Rondelle	d=5 DIN6799
72	E16002	16	Kulisse	<i>Guide slot/gate</i>	Coulisse/Grille	
73	E16003	24	Bolzen	<i>Pin</i>	Axe	D=8
74	E16031	2	Handhebel	<i>Hand lever</i>	Levier a main	
75	E70013	11	Verschraubung	<i>Adaptor</i>	Raccord	GE 15L R1/2-ED
76	E22005	2	Drossel	<i>Restrictor</i>	Etranglement	
77	E72045	6	Schlauch	<i>Hose</i>	Flexible	3/8"-1150-A12L90-A12L
78	E22006	1	Verschraubung	<i>Adaptor</i>	Raccord	
79	E70027	1	Verschraubung	<i>Adaptor</i>	Raccord	EW 15L
80	E70017	1	Verschraubung	<i>Adaptor</i>	Raccord	EGE 15L R1/2-ED
81	E70018	1	Verschraubung	<i>Adaptor</i>	Raccord	GE 8L R1/4-ED
82	E72049	1	Schlauch	<i>Hose</i>	Flexible	1/2"-3200-A15L-A15L
83	E91006	1	Schutzschlauch	<i>Protection hose</i>	Tuyau de protection	D=150 L=2600
84	E72047	8	Schlauch	<i>Hose</i>	Flexible	1/2"-3500-A15L90-I15L
85	E72048	1	Schlauch	<i>Hose</i>	Flexible	1/2"-3200-A15L90-A15L
86	E72044	1	Schlauch	<i>Hose</i>	Flexible	1/1"-870-A28L-A28L
87	E70033	1	Verschraubung	<i>Adaptor</i>	Raccord	RHZ 8L R1/4-ED
88	E53014	1	Dichtscheibe	<i>Packing washer</i>	Rondelle d'etan&cheite	DKA 1/4 A3CX
89	E22020	1	Verschraubung	<i>Adaptor</i>	Raccord	
90	E70011	1	Verschraubung	<i>Adaptor</i>	Raccord	GE 28L R1/1-ED
91	E70006	1	Verschraubung	<i>Adaptor</i>	Raccord	GE 18L R3/4-ED
92	E72043	1	Schlauch	<i>Hose</i>	Flexible	5/8"-820-A18L90-A18L
93	E71085	1	Leitung	<i>Pipe</i>	Tuyau	8x1,5
94	E71084	1	Leitung	<i>Pipe</i>	Tuyau	8x1,5