




F330A Standard 330AB001 BASE ASSEMBLY									
Pos	Code	Description	Um	Qty	From	To	W1	W2	
1	380983	BASE	NR	1.0	3144				
2	320779	BUSH	NR	*1.0					
3	BZ087	BUSH	NR	*1.0					
4	380042	COMPENSATOR	NR	1.0					
5	AS718	CIRCLIP	NR	1.0					
	330AB181	LUBRICATION SYSTEM	NR	1.0	3030				