

# D20

SECTIONAL VALVE



 **walvoil**  
MOTION BY PEOPLE

TECHNICAL CATALOGUE



 **walvoil**  
MOTION BY PEOPLE

**3<sup>rd</sup> edition Jan.2024**

---

**Additional information**

*This catalogue shows the product in the most standard configurations.  
Please contact Sales Dpt. for more detailed information or special request.*

**WARNING!**

*All specifications of this catalogue refer to the standard product at this date.  
Walvoil, oriented to a continuous improvement, reserves the right to  
discontinue, modify or revise the specifications, without notice.*

**WALVOIL IS NOT RESPONSIBLE FOR ANY DAMAGE CAUSED BY AN  
INCORRECT USE OF THE PRODUCT.**



### **Applications**

The valve is available with manual, hydraulic remote, pneumatic and electrohydraulic controls.

Working sections have auxiliary valves and a broad range of interchangeable spools.

Special versions for LS variable pumps can be realised on request.

Suitable for applications including Wheel loaders, Truck cranes, Drilling machines, Sea platform cranes, Presses, Compactor, Hook and Skip loaders.





QUICK REFERENCE GUIDE

GENERAL SPECIFICATION	D9	D3M	DVS10	D4	D6	D16	D12	DVS20	D20	D25	D40
Working sections number	1-12	1-12	1-12	1-12	1-12	1-12	1-12	1-12	1-12	1-12	1-10
<b>CIRCUIT</b>											
Parallel	•	•	•	•	•	•	•	•	•	•	•
Series	•	•	•	•	•	•	•		•	•	
Tandem	•	•	•	•	•	•		•	•		
Parallel circuit stroke (mm)	6	5	6	6	7	7	9,5	9,5	9,5	12	15
Series circuit stroke (mm)	6	5	6	6	5	7	6,5		6,5	8,5	
Float spool extra stroke (mm)	5	5	5	5,5	6	7	7	7	7	9,5	10
Spools pitch (mm)	31	38	35	40	46	46	56	56	64	75	91
<b>RATED FLOW</b>											
Max recommended flow rate (l/min)	35	55	45	80	100	150	180	250	250	380	700
Max recommended flow rate (GPM)	10	15	12	22	27	40	48	67	67	100	185
<b>RATED PRESSURE</b>											
Max working pressure (bar)*	315	350	350	350	315	350	350	250	350	350	350
Max working pressure (PSI)*	4500	5000	5000	5000	4500	5000	5000	4000	5000	5000	5000

NOTE (\*): Intermittent pressure at max. 1 million cycles with specific internal testing.

OPTION CHART	D9	D3M	DVS10	D4	D6	D16	D12	DVS20	D20	D25	D40
Direct acting pressure relief valve	•	•	•	•							
Pilot operated pressure relief valve		•		•	•	•	•	•	•	•	•
2 stage pilot operated relief valve		•		•	•	•	•		•	•	•
Externally piloted valve	•	•	•	•	•	•	•		•	•	•
Solenoid dump valve (12 Vdc)	•	•	•	•	•	•	•				
Solenoid dump valve (24 Vdc)	•	•	•	•	•	•	•				
Main anticavitation check valve		•		•	•	•	•	•	•	•	•
Clamping valve		•	•	•							
<b>SPOOL ACTUATION</b>											
Manual control	•	•	•	•	•	•	•	•	•	•	•
Without lever	•	•	•	•	•	•	•	•	•	•	•
90° joystick control		•	•	•	•	•					
Hydraulic control	•	•	•	•	•	•	•	•	•	•	•
Direct electric control (12-24 Vdc)		•		•							
<b>SPOOL RETURN ACTION</b>											
Spring return	•	•	•	•	•	•	•	•	•	•	•
Detent in A - in B - in A/B	•	•	•	•	•	•	•	•	•	•	•
Detent in 4 <sup>th</sup> position	•	•	•	•	•	•	•	•	•	•	•
Arrangement for dual control	•	•		•	•	•	•		•		
Hydraulic load limit	•	•		•	•	•					
Pneumatic control ON - OFF		•	•	•	•	•	•	•	•		
Proportional pneumatic control		•	•	•	•	•	•	•	•		
Electrical load limit	•	•		•	•	•					
Electrohydraulic control ON-OFF (12-24 Vdc)		•	•	•	•	•	•	•	•		
Electrohydraulic control PROP. (12-24 Vdc)		•	•	•	•	•	•	•	•		
Electropneumatic control (12-24 Vdc)		•	•	•	•	•	•		•		
<b>AUXILIARY VALVES</b>											
Antishock valve	•	•	•	•	•	•	•	•	•	•	•
Anticavitation valve	•	•	•	•	•	•	•	•	•	•	•
Combined valve	•	•	•		•	•	•		•	•	•
Pilot combined valve						•		•	•	•	•



## GENERAL INDEX

<b>4</b>	<b>General specifications</b> Standard working conditions Fluid options
<b>5</b>	<b>Order example</b> Standard thread Thread codes Tie-rod kit classification Painting
<b>7</b>	<b>Dimensions</b>
<b>8</b>	<b>Typical curves</b> Pressure drop (P - T) Pressure drop (P - A/B) Pressure drop (A/B - T) Direct relief valve curve Combined valve curve Antishock valve curve Anticavitation check valve curve
<b>10</b>	<b>Inlet Section</b> Order example Inlet side classification Valve identification Valve arrangement Inlet position and available thread type
<b>14</b>	<b>Working section</b> Order example Spool identification Spool actuation classification for manual control Spool actuation classification for hydraulic control Spool return action classification - Spring load values Work section identification Auxiliary valves identification
<b>25</b>	<b>Intermediate inlet section</b> Order example Intermediate inlet section classification Valve identification on intermediate inlet section Valve arrangement on intermediate inlet section Inlet position and available thread type
<b>29</b>	<b>Intermediate outlet section</b> Order example Intermediate outlet section classification Inlet position and available thread type (for BF intermediate) Inlet position and available thread type (for BG intermediate)
<b>32</b>	<b>Outlet section (version 1 outlet)</b> Order example
<b>32</b>	<b>Outlet section (HPCO version outlet)</b> Order example - HPCO version outlet Outlet with single tank classification Outlet with two tanks classification Carry-over connection (HPCO)
<b>36</b>	<b>D20 Spare parts list</b> Gasket kits
<b>39</b>	<b>Installation and maintenance</b>
<b>41</b>	<b>General conditions and patents</b>



**GENERAL SPECIFICATIONS**

**Standard working conditions**

Description	Value
Ambient operating temperature range	-40°C / +60°C
Kinematic viscosity range	10 ÷ 300 cSt
Max contamination level	9 (NAS 1638) - 20/18/15 (ISO 4406:1999)
Recommended filtration level	b10 > 75 (ISO 16889:2008)
Internal filter (on electroproportional valves pilot line)	30 µm

All information and diagrams in this catalogue refer to a mineral base oil VG46 at 50°C temperature (32 cSt kinematic viscosity)

**Fluid options**

Types of fluid (according to ISO 6743/4) Oil and Solutions	Temperature (°C)		Compatible gasket
	min	max	
Mineral Oil HL, HM (or HLP acc. to DIN 51524)	-25	+80	NBR
Oil in water emulsions HFA	+5	+55	NBR
Water in oil emulsions HFB	+5	+55	NBR
Polyglycol-based aqueous solution HFC	-10	+60	NBR

For special applications and different fluids, please call our Technical Department.



**ORDER EXAMPLE**

**D20/1: IR 009 150 A G06 W001A H005 RP G06 01 PA 100 01 PB 100 TJ A G07**

**TYPE:**

**D20:** product type  
**/1:** working section number

**1) INLET ARRANGEMENT: pag. 10**

**IR 009** inlet side and valve type  
**150** setting (bar)  
**A G06** inlet position and available thread type


**2) WORK SECTION ARRANGEMENT: pag. 14**

**W001A** spool type  
**H005** spool actuation type  
**RP G06** type and thread section  
**01 PA 100** auxiliary valve (port A)  
**01 PB 100** auxiliary valve (port B)

**3) OUTLET ARRANGEMENT: pag. 32**

**TJ** outlet type  
**A G07** outlet position and available thread type

Ordering row 2 must be repeated for every work section



**Standard thread**


The connection ports size is indicated by an ordering code common for all Hydrocontrol products. Following table shows all available connections; for ordering code refer to table on page 40.

ports	BSP (ISO-228)	UN-UNF (ISO-725)	SAE 3000 (ISO 6162-1)	SAE 6000 (ISO 6162-6)
<b>Inlet Port (P)</b>	G 1 - G 1 1/4 <b>G06-G07</b>	1 5/16 - 12 UNF <b>U06</b>	1" MA - 1" UNC <b>S05-S06</b>	3/4" MA - 3/4" UNC <b>S33-S34</b>
<b>Ports (A - B)</b>	G 1 - G 1 1/4 <b>G06-G07</b>	1 5/16 - 12 UNF <b>U06</b>	1" MA - 1" UNC <b>S05-S06</b>	3/4" MA - 3/4" UNC <b>S33-S34</b>
<b>Outlet (T)</b>	G 1 1/4 <b>G07</b>	1 5/8 - 12 UNF <b>U06</b>	1 1/4 MA - 1 1/4 UNC <b>S07-S08</b>	-
<b>Carry over (HPCO)</b>	G 1 1/4 <b>G07</b>	1 5/8 - 12 UNF <b>U07</b>	1 1/4 MA - 1 1/4 UNC <b>S07-S08</b>	1" MA - 1" UNC <b>S35-S36</b>
<b>Hydraulic Pilot</b>	G 1/4 <b>G02</b>	9/16" - 18 UNF <b>U02</b>	-	-
<b>Pneumatic Pilot</b>	G 1/8	NPTF 1/8-27		



**Tie-rod kit classification (appendix "A")**

Tie rod kit allows the correct assembly of sectional valves. Tie rod's length depends on the number of sections; each valve is assembled with tie rod kits including a tie rod, two nuts and two washers. D20 requires 4 tie-rod kits.



Tie rod kit	Order Code	Length (mm)	Clamping Torque (Nm)	Quantity
D20/1	300108001	248		
D20/2	300108002	312		
D20/3	300108003	376		
D20/4	300108004	440		
D20/5	300108005	504		
D20/6	300108006	568		
D20/7	300108007	632	110	4
D20/8	300108008	696		
D20/9	300108009	760		
D20/10	300108010	824		
D20/11	300108011	888		
D20/12	300108012	952		

**Painting**

On request, all Hydrocontrol valves can be delivered painted (RAL 9005 black primer).


**Order example of D20/1 painted:**

D20/1  
IR 009 150 A G06  
W001A H001 F001A RP G06 01 PA 100 01 PB 100  
TJ A G07

**P006/1 N10**

The painting is indicated with the following value:


**P006 - /1 - N10**







DIMENSIONS





TYPE	/1	/2	/3	/4	/5	/6	/7	/8	/9	/10	/11	/12
X (mm)	195	259	323	387	451	515	579	643	707	771	835	899
Y (mm)	223	287	351	415	479	543	607	671	735	799	863	927
Weights (kg)	28,6	39,6	50,6	61,6	72,6	83,6	94,6	105,5	116,4	127,4	138,4	149,4





TYPICAL CURVES

Indicated values have been tested with standard sectional valve and W001A spool.



Pressure drop (P - T)



Pressure drop (P - A/B)




Pressure drop (A/B - T)



Pilot operated relief valve curve

Setting ranges	
type	pressure (bar)
A	0 - 350






**TYPICAL CURVES**

Indicated values have been tested with standard sectional valve and W001A spool.


**Antishock valve curve**

Setting ranges		
type	pressure (bar)	
	at full flow	at min. flow
A	0 - 70	0-A / 50-A
A	71 - 120	51-A / 70-A
B	121 - 150	71-A / 110-A
C	151 - 300	111-A / 240-A
D	301 - 350	241-A / 350-A




**Combined valve curve**


Setting ranges		
type	pressure (bar)	
	at full flow	at min. flow
A	50 - 130	20-A / 100-A
B	131 - 220	101-A / 220-A
C	221 - 260	221-A / 350-A



**Main anticavitation check valve curve**



**Anticavitation check valve curve**






**INLET SECTION**

Order example

<b>IR</b>	<b>009</b>	<b>150</b>	<b>A G05</b>
-----------	------------	------------	--------------

- 1. IR** inlet side classification
- 1. 009** valve arrangement
- 150** setting (bar)
- 2. A G06** inlet position and available thread type




Rif.	Code	Description	Page
-	<b>IR</b>	Sectional valve with right inlet section	<b>11</b>
	<b>IL</b>	Sectional valve with left inlet section	
<b>1</b>	<b>009</b>	Pilot operated pressure relief valve	
	<b>010</b>	Pilot operated pressure relief valve and Main anticavitation check valve	<b>12</b>
	<b>019</b>	Without valves	
<b>2</b>	<b>A G06</b>	Upper inlet (thread G 1)	
	<b>A G07</b>	Upper inlet (thread G 1"1/4)	
	<b>A U07</b>	Upper inlet (thread 1"5/8 - 12 UNF)	<b>13</b>
	<b>A S05</b>	Upper inlet (thread SAE 3000 1" MA)	
	<b>A S33</b>	Upper inlet (thread SAE 6000 3/4" MA)	

**NOTE:** when ordering a relief valve it is necessary to specify factory setting (example 150).




**Inlet side classifications**



**Valve identification**

type	schema	layout	description	type	schema	layout	description
<b>2</b>			Pilot operated pressure relief valve	<b>5</b>			2 stage pilot operated relief valve
<b>3</b>			Relief valve plugged	<b>6</b>			Externally piloted valve
<b>4</b>			Main anticavitation check valve	<b>11</b>			Plug with pressure-gauge connection

**Valve arrangement**



**Combination valve example: 009 = 2A - 3B**













- 009** Combination valve
- 2A** Pressure relief valve in port A
- 3B** Relief valve plugged in port B

**The code identifies:**  
with a number, the type of valve; with a letter its position on the inlet section.

- (A) = spool action side
- (B) = spool return action side

**NOTE:** when ordering a main relief valve it is necessary to specify setting



VALVE COMBINATION INLET SECTION		Valve type on port B						
								
		2	3	4	5	6	11	
Valve type on port A		2		009	010		011	016
		3	018	019	020	021	022	027
		4	029	030		031	032	037
		5		038				
		6	047	048				
		11	085					

**NOTE: Valve combinations 021, and 038 requires double setting (see example).**





Order example for inlet section: IR **038 200\*280** A G05

**038**  
**200\*380**

valve combination \_\_\_\_\_  
double range setting (bar) \_\_\_\_\_



Inlet combination and thread available	
<b>A G06</b>	Upper inlet (thread G 1)
<b>A G07</b>	Upper inlet (thread G 1 1/4)
<b>A U07</b>	Upper inlet (thread 1 5/8 - 12 UNF)
<b>A S05</b>	Upper inlet (thread SAE 3000 - 1" MA)
<b>A S06</b>	Upper inlet (thread SAE 3000 - 1" UNC)
<b>A S33</b>	Upper inlet (thread SAE 6000 - 3/4" MA)
<b>A S34</b>	Upper inlet (thread SAE 6000 - 3/4" UNC)
<b>B G06</b>	Upper inlet P1 with pressure-gauge connection G 1/4 (thread G 1)
<b>B G07</b>	Upper inlet P1 with pressure-gauge connection G 1/4 (thread G 1 1/4)
<b>B U07</b>	Upper inlet P1 with pressure-gauge connection G 1/4 (thread 1 5/8 - 12 UNF)
<b>B S05</b>	Upper inlet P1 with pressure-gauge connection G 1/4 (thread SAE 3000 - 1" MA)
<b>B S06</b>	Upper inlet P1 with pressure-gauge connection G 1/4 (thread SAE 3000 - 1" UNC)
<b>B S33</b>	Upper inlet P1 with pressure-gauge connection G 1/4 (thread SAE 6000 - 3/4" MA)
<b>B S34</b>	Upper inlet P1 with pressure-gauge connection G 1/4 (thread SAE 6000 - 3/4" UNC)
<b>C G06</b>	Central side inlet (thread G 1)
<b>C G07</b>	Central side inlet (thread G 1 1/4)
<b>C U07</b>	Central side inlet (thread 1 5/8 - 12 UNF)
<b>C S05</b>	Central side inlet (thread SAE 3000 - 1" MA)
<b>C S06</b>	Central side inlet (thread SAE 3000 - 1" UNC)
<b>C S33</b>	Central side inlet (thread SAE 6000 - 3/4" MA)
<b>C S34</b>	Central side inlet (thread SAE 6000 - 3/4" UNC)
<b>D G06</b>	Central side inlet P1 with pressure-gauge connection G 1/4 (thread G 1)
<b>D G07</b>	Central side inlet P1 with pressure-gauge connection G 1/4 (thread G 1 1/4)
<b>D U07</b>	Central side inlet P1 with pressure-gauge connection G 1/4 (thread 1 5/8 - 12 UNF)
<b>D S05</b>	Central side inlet P1 with pressure-gauge connection G 1/4 (thread SAE 3000 - 1" MA)
<b>D S06</b>	Central side inlet P1 with pressure-gauge connection G 1/4 (thread SAE 3000 - 1" UNC)
<b>D S33</b>	Central side inlet P1 with pressure-gauge connection G 1/4 (thread SAE 6000 - 3/4" MA)
<b>D S34</b>	Central side inlet P1 with pressure-gauge connection G 1/4 (thread SAE 6000 - 3/4" UNC)






WORKING SECTION

Order example:

<b>W001A</b>	<b>H005</b>	<b>RP G06</b>	<b>01 PA 100</b>	<b>01 PB 100</b>
--------------	-------------	---------------	------------------	------------------

- |   |   |
|---|---|
| <ol style="list-style-type: none"> <li>1. <b>W001A</b></li> <li>2. <b>H005</b></li> <li>3. <b>RP G06</b></li> <li>4. <b>01 PA 100</b></li> <li>5. <b>01 PB 100</b></li> </ol> | <p>spool type _____</p> <p>spool actuation type _____</p> <p>section and thread type _____</p> <p>auxiliary valve (port A - handle side) _____</p> <p>auxiliary valve (port B - cap side) _____</p> |
|---|---|



Rif.	Code	Description	Page
1	<b>W001</b>	3 positions double-acting	<b>15</b>
	<b>W002</b>	3 positions double-acting A-B to tank	
2	<b>H101</b>	Unprotected lever	<b>17</b>
	<b>H005*</b>	hydraulic actuation	
3	<b>RP G06</b>	Parallel circuit (G 1)	<b>23</b>
	<b>RP U06</b>	Parallel circuit (1"5/16-12 UNF)	
	<b>RS G06</b>	Series circuit (G 1)	
	<b>RS U06</b>	Series circuit (1"5/16-12 UNF)	
4	<b>01 PA 100</b>	Antishock valve (port A)	<b>24</b>
	<b>05 PA</b>	Prearrangement for auxiliary valve (port A)	
5	<b>01 PB 100</b>	Antishock valve (port B)	<b>24</b>
	<b>05 PB</b>	Prearrangement for auxiliary valve (port B)	

**NOTE:** (\*) Leave out the spool return action code when choosing H005.  
 Sections designed to house auxiliary valve option require double choice on work ports A and B.  
 Always indicate setting value when using antishock and combined valve: **01 PA (100) - 03 PA (100)**





**Spool identification**

order example of spool: **W001 A J10**

**W001** spool schema 3 positions double-acting  
**A** spool type standard spool  
**J10** restricted service ports restriction on diameter (0,10 mm in A and B)

<b>W001</b>	3 positions double-acting	
<b>W002</b>	3 positions double-acting A and B to tank	
<b>W003</b>	3 positions double-acting A to tank B blocked	
<b>W004</b>	3 positions double-acting A blocked B to tank	
<b>W005</b>	3 positions single - acting on A	
<b>W006</b>	3 positions single - acting on B	
<b>W009</b>	3 positions double-acting with anticavitation valves	
<b>W010</b>	3 positions double-acting switch port closed (A - B blocked)	
<b>W011</b>	3 positions double-acting switch port closed (A - B to tank)	
<b>W012</b>	4 positions double-acting with float in the 4th position	
<b>W013</b>	3 positions double-acting regenerative	
<b>W015</b>	3 positions double-acting series	
<b>W016</b>	3 positions double-acting series A and B to tank	



spools with restricted service ports				
code	circuit	restriction on diameter (mm)	section (mm <sup>2</sup> )	hydraulic schema
J10	A-B IN T	0,10	4,08	
K10	A IN T	0,10	4,08	
Y10	B IN T	0,10	4,08	

CODE	spool type available	
	STANDARD A	METERED B
W001	W001A	W001B
W002	W002A	W002B
W003	W003A	W003B
W004	W004A	W004B
W005	W005A	W005B
W006	W006A	W006B
W009	W009A	W009B
W010	W010A	
W011	W011A	
W012	W012A	
W013	W013A	
W015	W015A	
W016	W016A	





NOTE:

- W012, W013, spools need a special machining on the valve body.
- W015, W016, spools need RS type body.
- Float spool (W012) need special detent kit (F005).
- Regenerative spool (W013) need special return spring kits.
- Different spools are available on request.



Please contact our Sales department for more information.



**Spool actuation classification for manual control**

code	description	dimensions	configuration
<b>H004</b>	Control without lever		
<b>H101</b>	Unprotected lever		
<b>H102</b>	Unprotected lever rotated 180°		

**Spool actuation classification for Hydraulic control**


code	description	dimensions	configuration
<b>H005</b> leave out the spool return action code	Hydraulic actuation with side ports  BSP ports = G 1/4 UNF ports = 9/16-18 UNF		
<b>H006</b> leave out the spool return action code	Hydraulic actuation with side ports and cast-iron end caps  BSP ports = G 1/4 UNF ports = 9/16-18 UNF		



**Spool return action classification - Springs load values**

Spool return kits have three different spring types; following the codes depending on spring loads.

Spring type			
Code	A (standard spring)	B (soft spring)	C (heavy spring)
<b>Preloading</b>	196.2 N	145.1 N	313.9 N
<b>End of stroke</b>	245.2 N	176.6 N	412 N
Spool return action identification example			
<b>Code</b>	<b>F001A</b>	<b>F001B</b>	<b>F001C</b>














**Spool return action classification**

code	description	schema	dimensions	configuration
<b>F001A</b> <b>F001B</b> <b>F001C</b>	3 positions spring-centred spool			
<b>F002A</b>	3 positions spring-centred spool detent in A and B			
<b>F003A</b>	3 positions spring-centred spool detent in A			
<b>F004A</b>	3 positions spring-centred spool detent in B			
<b>F005A</b>	4 positions spring-centred spool detent in 4 <sup>th</sup> position  (only for W012 spool)			
<b>F013A</b> <b>F013B</b> <b>F013C</b>	3 positions spring-centred spool prearrangement dual command			




**Pneumatic control classification**

code	description	schema	dimensions	configuration
<b>F020A</b>	Pneumatic control ON - OFF			
<b>F021A</b>	Pneumatic control ON - OFF rotated 180°			
<b>F022A</b>	Proportional Pneumatic control		Proportional control with port BSP: G 1/8	
<b>F023A</b>	Proportional Pneumatic control rotated 180°			
<b>F135A</b>	Pneumatic control ON - OFF			
<b>F136A</b>	Pneumatic control ON - OFF rotated 180°			
<b>F126A</b>	Proportional Pneumatic control		Proportional control with port NPTF: 1/8-27	
<b>F127A</b>	Proportional Pneumatic control rotated 180°			

**Proportional pneumatic control curve**

The diagram shows the spool stroke as a function of the pneumatic pressure operating.







**Electrohydraulic control specifications**

Operating temperature range	-20°C / +80°C
Max inlet pressure	350 bar
Reduced pressure	16 bar
Back pressure on (T)	3 bar
Filtering degree	25 μ assoluti
Raccomanded pilot pipe size	Ø 6 mm - G 1/4

**Electrohydraulic ON-OFF control with fixed pressure reducing valve**



**Electrohydraulic PROPORTIONAL control with fixed pressure reducing valve**



Proportional control kit, mechanically retrooperated, allows the maximum precision of positioning, limiting the hysteresis. The control is operated with PWM control of the current. PWM frequency suggest: 60-80 Hz

regulation currents			
Nominal voltage (V)	Resistance R <sub>20</sub> (Ohm)	Current min (A)	Current max (A)
12 vdc	3,7	0,9	1,7
24 vdc	15,5	0,45	0,85



**Electrohydraulic control classification**

code	description	dimensions	configuration
<b>F1600</b>	3 positions electrohydraulic control ON - OFF 12 Vdc		
<b>F1610</b>	3 positions electrohydraulic control ON - OFF 24 Vdc		
<b>F2600</b>	3 positions electrohydraulic control PROPORTIONAL 12 Vdc		
<b>F2610</b>	3 positions electrohydraulic control PROPORTIONAL 24 Vdc		

Electrohydraulic ON-OFF control is stackable with electrohydraulic PROPORTIONAL control (F2600 = F2610). Control kit already includes orifice to make spool displacement more gradual.



**Electrohydraulic control with fixed pressure reducing valve classification**

code	description	configuration
<b>F1500</b>	Electrohydraulic control ON - OFF (fixed pressure reducing valve) P - T inlet side (12 vdc)	 <p>Port BSP (P - T) = G 1/4 Port UNF (P - T) = 9/16"18 UNF</p>
<b>F1510</b>	Electrohydraulic control ON - OFF (fixed pressure reducing valve) P - T inlet side (24 vdc)	
<b>F2500</b>	Electrohydraulic control PROPORTIONAL (fixed pressure reducing valve) P - T inlet side (12 vdc)	
<b>F2510</b>	Electrohydraulic control PROPORTIONAL (fixed pressure reducing valve) P - T inlet side (24 vdc)	
<b>F1520</b>	Electrohydraulic control ON - OFF (fixed pressure reducing valve) P inlet - T outlet (12 vdc)	 <p>Port BSP (P - T) = G 1/4 Port UNF (P - T) = 9/16"18 UNF</p>
<b>F1530</b>	Electrohydraulic control ON - OFF (fixed pressure reducing valve) P inlet - T outlet (24 vdc)	
<b>F2520</b>	Electrohydraulic control PROPORTIONAL (fixed pressure reducing valve) P inlet - T outlet (12 vdc)	
<b>F2530</b>	Electrohydraulic control PROPORTIONAL (fixed pressure reducing valve) P inlet - T outlet (24 vdc)	

**Control tie rod assembly**

The length of the control tie rod, will change depending on the section numbers; in this way it will be easy to install in the right way the sections and avoid any misassembly. Each kit is composed by 2 tie rods, 2 plugs, 2 connection ports and spacers according to the section number.


**NOTE:** the control tie rod kit has always to be ordered separately.

Reducing valve, combined with electrohydraulic control kit has to be calculated as a normal working section.

**ORDER EXAMPLE:**

Complete valves with 3 sections F1600 requires a complete tie-rod kit /3.

Complete valves with 2 sections F1600 and 1 section with F1500 (reducing valve) requires a complete tie-rod kit /4.



**Order code fixed pressure reducing valve:**

**915000303** = reducing valve for BSP ports

**915000312** = reducing valve for UNF ports

**Order code for control tie rod (BSP):**

- 320103001** = control tie rod /1
- 320108001** = control tie rod /2
- 320108002** = control tie rod /3
- 320108003** = control tie rod /4
- 320108004** = control tie rod /5
- 320108005** = control tie rod /6
- 320108006** = control tie rod /7
- 320108007** = control tie rod /8
- 320108008** = control tie rod /9

**Order code for control tie rod (UNF):**

- 320103026** = control tie rod /1
- 320108012** = control tie rod /2
- 320108013** = control tie rod /3
- 320108014** = control tie rod /4
- 320108015** = control tie rod /5
- 320108016** = control tie rod /6
- 320108017** = control tie rod /7
- 320108018** = control tie rod /8
- 320108019** = control tie rod /9



Compatibility table

SPOOL ACTION TYPE	SPOOL TYPE																				
	W001A	W001B	W002A	W002B	W003A	W003B	W004A	W004B	W005A	W005B	W006A	W006B	W009A	W009B	W010A	W011A	W012A	W013A	W015A	W016A	
H101	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•
H102	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•
H004	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•
H005	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•
H006	•	•	•	•	•	•	•	•					•	•			•		•	•	•
SPOOL RETURN ACTION TYPE	SPOOL TYPE																				
	W001A	W001B	W002A	W002B	W003A	W003B	W004A	W004B	W005A	W005B	W006A	W006B	W009A	W009B	W010A	W011A	W012A	W013A	W015A	W016A	
F001	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•		•	•	•	•
F002	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•			•	•	•
F003	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•			•	•	•
F004	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•			•	•	•
F005																	•				
F013	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•		•	•	•	•
F020=F021	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•		•	•	•	•
F022=F023	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•		•	•	•	•
F135=F136	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•		•	•	•	•
F126=F127	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•		•	•	•	•
F0620=F0630	•	•	•	•	•	•	•	•					•	•	•	•		•	•	•	•
F1500=F1510	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•		•	•	•	•
F1520=F1530	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•		•	•	•	•
F2500=F2510	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•		•	•	•	•
F2520=F2530	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•		•	•	•	•
F1600=F1610	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•		•	•	•	•





**Work section identification**

working section type	
<b>RP G06</b>	
<b>RP G07</b>	
<b>RP U06</b>	
<b>RP S05</b>	
<b>RP S06</b>	
<b>RP S33</b>	
<b>RP S34</b>	

Parallel circuit section

When the spool is operated it intercepts the by-pass gallery by diverting the flow of oil to service port A or B. If two or more spools are actuated at the same time, the oil will power the service port that has the lower load; by throttling the spools, the flow of oil can be divided between two or more service ports.









<b>RS G06</b>	
<b>RS G07</b>	
<b>RS U06</b>	
<b>RS S05</b>	
<b>RS S06</b>	
<b>RS S33</b>	
<b>RS S34</b>	









Series circuit section

When the spool is operated it intercepts the switch gallery by diverting the flow of oil to service port A or B. The oil that flows back from the actuator is carried to the switch gallery thus making it available to the service ports downstream from the series section. The pressure drop downstream is added to the pressure drop of the section itself.



**Auxiliary valve identification**

code	description	schema	configuration	setting range (bar)			
				type	at full flow	type	at min. flow
01 PA	Antishock valve (port A)			A	0 / 70	A	0-A / 50-A
				B	71 / 120	B	51-A / 70-A
				C	121 / 150	C	71-A / 110-A
				D	151 / 300	D	111-A / 240-A
				E	301 / 350	E	241-A / 350-A
02 PA	Anticavitation valve (port A)						
04 PA	Pilot combined valve (port A)			A	30 / 110		
				B	111 / 350		
05 PA	Prearrangement for auxiliary valve (port A)						

code	description	schema	configuration	setting range (bar)			
				type	at full flow	type	at min. flow
01 PB	Antishock valve (port B)			A	0 / 70	A	0-A / 50-A
				B	71 / 120	B	51-A / 70-A
				C	121 / 150	C	71-A / 110-A
				D	151 / 300	D	111-A / 240-A
				E	301 / 350	E	241-A / 350-A
02 PB	Anticavitation valve (port B)						
04 PB	Pilot combined valve (port B)			A	30 / 110		
				B	111 / 350		
05 PB	Prearrangement for auxiliary valve (port B)						

**Auxiliary valve - Setting range**

Sections designed to house auxiliary valve option require double choice on work ports A and B. Always indicate setting value when using antishock valve and pilot combined valve:

- 01 PA (120) = setting at full flow**
- 01 PA (120-A) = setting at min. flow**
- 04 PA (120) = setting at min. flow**




**INTERMEDIATE INLET SECTION**

**Order example**

<b>BE</b>	<b>009</b>	<b>150</b>	<b>A G06</b>
-----------	------------	------------	--------------

- 1. BE** inlet side
- 1. 009** valve arrangement
- 150** setting (bar); when ordering a main relief valve it is necessary to specify setting
- 2. A G06** inlet position and available thread type



Rif.	Code	Description	Page
-	<b>BE</b>	Intermediate inlet section	<b>26</b>
	<b>BV*</b>	Intermediate inlet section with pressure relief valve	
<b>1</b>	<b>009</b>	Pilot operated pressure relief valve	<b>27</b>
	<b>010</b>	Pilot operated pressure relief valve and Main anticavitation check valve	
	<b>019</b>	Without valves	
	<b>020</b>	Main anticavitation check valve	
<b>2</b>	<b>A G06</b>	Upper inlet (thread G 1)	
	<b>A U06</b>	Upper inlet (thread 1"5/16-12 UNF)	

**NOTE:** when ordering a relief valve it is necessary to specify factory setting (example 150).  
 \* = omit the code for inlet positioning and thread



Intermediate inlet section classifications

**intermediate inlet type**

<b>BE</b>			Intermediate inlet section
-----------	--	--	----------------------------

The intermediate inlet section is driven by two pumps (P + P1). The downstream elements can be set to a lower pressure than the upstream ones by adjusting the pressure relief valve of the intermediate section in question.


<b>BV</b>			Intermediate inlet section with pressure relief valve
-----------	--	--	---

The intermediate inlet section and the elements are driven by a single pump (P). The downstream elements can be set to a lower pressure than the upstream ones by adjusting the pressure relief valve of the intermediate section in question.

Valve identification on intermediate inlet section

type	schema	layout	description	type	schema	configurazione	descrizione
<b>2</b>			Pilot operated pressure relief valve	<b>4</b>			Externally piloted valve
<b>3</b>			Relief valve plugged	<b>11</b>			Plug with pressure-gauge connection

Valve arrangement on intermediate inlet section



**Combination valve example: 009 = 2A - 3B**

- 009** Combination valve
- 2A** Pressure relief valve in port A
- 3B** Relief valve plugged in port B









**The code identifies:**


with a number, the type of valve; with a letter its position on the inlet section.

- (A) = spool action side
- (B) = spool return action side

**NOTE:** when ordering a main relief valve it is necessary to specify setting



		Valve type on port B				
						
VALVE COMBINATION INLET SECTION		2	3	4	11	
Valve type on port A		2		009	010	016
		3	018	019	020	027
		4	029	030		
		11	085	086		

Inlet combination and thread available	
A G06	 <p>Upper inlet</p>
A G07	
A U06	
A S05	
A S06	
A S33	
A S34	



**Complete configuration samples for D20/2 with intermediate inlet section (BE)**


IR 009 150 A G06 ..... Right inlet section

W001A H101 F001A RP G06..... Working section

**BE 009 150 A G06 .....Intermediate inlet section**

W001A H101 F001A RP G06..... Working section

TJ A G07 ..... Outlet section



**Complete configuration samples for D20/2 with intermediate inlet section (BV)**


IR 009 150 A G06 ..... Right inlet section

W001A H101 F001A RP G06..... Working section

**BV 009 150 .....Intermediate inlet section**

W001A H101 F001A RP G06..... Working section

TJ A G07 ..... Outlet section






**INTERMEDIATE OUTLET SECTION**

**Order example**

**BF** | **A G07**

1. **BF** inlet side \_\_\_\_\_  
**A G07** inlet position and available thread type \_\_\_\_\_





Rif.	Code	Type	Description	Page
-	<b>BF</b>		Intermediate outlet section with single tank return	
	<b>BG</b>		Intermediate outlet section with two tank returns	
1	<b>A G07</b>		Upper outlet (thread G 1"1/4)	30
	<b>A U07</b>		Upper outlet (thread 1"5/8-12 UNF)	
	<b>G G07</b>	for	Front outlet side A (thread G 1"1/4)	
	<b>G U07</b>	BF	Front outlet side A (thread 1"5/8-12 UNF)	
	<b>H G07</b>		Rear outlet side B (thread G 1"1/4)	
	<b>H U07</b>		Rear outlet side B (thread 1"5/8-12 UNF)	
	<b>J G07</b>	for	Upper outlet HPCO - front side A and rear side B to T (thread G 1"1/4)	
	<b>J U07</b>	BG	Upper outlet HPCO-front side A and rear side B to T (thread 1"5/8-12 UNF)	





Intermediate outlet section classifications

**intermediate outlet type**




<b>BF</b>	 	<p>Intermediate outlet section with <b>single tank return</b></p>
-----------	--	---

The above outlet section allows the flow of oil of the two pumps and the tank ports to be piped to a single outlet T.

<b>BG</b>	 	<p>Intermediate outlet section with <b>two tank returns</b></p>
-----------	--	---

The section in question allows the flow of oil of the two pumps to be piped in two outlets: HPCO for powering another directional control valve, T for discharge of the work ports. In order to obtain this, the two T need to be linked.


**Outlet position and available thread type (for BF intermediate)**

<b>Outlet combination and thread available</b>		
A G07 A U07 A S07 A S08	 <p style="text-align: right;">Outlet (T)</p>	Upper outlet (T)
G G07 G U07 G S07 G S08	 <p style="text-align: right;">Outlet (T)</p>	Front outlet side A (T)
H G07 H U07 H S07 H S08	 <p style="text-align: right;">Outlet (T)</p>	Rear outlet side B (T)






**Outlet position and available thread type (for BG intermediate)**

Inlet combination and thread available	
<b>J G07</b>	
<b>J U07</b>	
<b>J S07</b>	
<b>J S08</b>	

Upper outlet HPCO front side A and rear side B to T


**Complete configuration samples for D20/2 with intermediate outlet section (BF)**

- IR 009 150 A G06 ..... Right inlet section
- W001A H101 F001A RP G06..... Working section
- BF A G07 .....Intermediate outlet section**
- W001A H101 F001A RP G06..... Working section
- IL 009 150 A G06 ..... Left inlet section



**Complete configuration samples for D20/2 with intermediate outlet section (BG)**


- IR 009 150 A G06 ..... Right inlet section
- W001A H101 F001A RP G06..... Working section
- BG J G07 .....Intermediate outlet section**
- W001A H101 F001A RP G06..... Working section
- IL 009 150 A G06 ..... Left inlet section





**OUTLET SECTION (VERSION 1 OUTLET)**

Order example




**TJ** | **A G07**

1. **TJ** outlet section type
2. **A G07** outlet position and available thread type

Rif.	Code	Description	Page
1	<b>TJ</b>	Outlet section with single return (T) right-side inlet (P)	
	<b>TK</b>	Outlet section with single return (T) left-side inlet (P)	
2	<b>A G07</b>	Upper outlet (thread G 1"1/4)	33
	<b>A U07</b>	Upper outlet (thread 1"5/8-12 UNF)	
	<b>A S07</b>	Upper outlet (thread SAE 3000 - 1"1/4 MA)	
	<b>A S08</b>	Upper outlet (thread SAE 3000 - 1"1/4 UNC)	
	<b>C G07</b>	Central outlet (thread G 1"1/4)	
	<b>C U07</b>	Central outlet (thread 1"5/8-12 UNF)	
	<b>C S07</b>	Central outlet (thread SAE 3000 - 1"1/4 MA)	
<b>C S08</b>	Central outlet (thread SAE 3000 - 1"1/4 UNC)		

**OUTLET SECTION (HPCO VERSION OUTLET)**

Order example - HPCO version Outlet




**TM** | **M G07**






1. **TM** outlet section type
2. **M G07** outlet position and available thread type

Rif.	Code	Description	Page
1	<b>TM</b>	Outlet section with two return (T-HPCO) right-side inlet (P)	
	<b>TN</b>	Outlet section with two return (T-HPCO) left-side inlet (P)	
2	<b>M G07</b>	HPCO upper outlet T (tank) rear outlet side B (thread G 1"1/4)	34
	<b>M U07</b>	HPCO upper outlet T (tank) rear outlet side B (thread 1"5/8-12 UNF)	
	<b>M S07</b>	HPCO upper outlet T (tank) rear outlet side B (thread SAE 3000 - 1"1/4 MA)	
	<b>M S08</b>	HPCO upper outlet T (tank) rear outlet side B (thread SAE 3000 - 1"1/4 UNC)	
	<b>N G07</b>	HPCO upper outlet T (tank) front outlet side A (thread G 1"1/4)	
	<b>N U07</b>	HPCO upper outlet T (tank) front outlet side A (thread 1"5/8-12 UNF)	
	<b>N S07</b>	HPCO upper outlet T (tank) front outlet side A (thread SAE 3000 - 1"1/4 MA)	
	<b>N S08</b>	HPCO upper outlet T (tank) front outlet side A (thread SAE 3000 - 1"1/4 UNC)	



Outlet with single tank classification



outlet combination and thread available			
<b>A G07</b>		Upper outlet (thread G 1"1/4)	
<b>A U07</b>		Upper outlet (thread 1"5/8 - 12 UNF)	
<b>A S07</b>		Upper outlet (thread SAE 3000 - 1"1/4 MA)	
<b>A S08</b>		Upper outlet (thread SAE 3000 - 1"1/4 UNC)	
<b>C G07</b>		Central outlet (thread G 1"1/4)	
<b>C U07</b>		Central outlet (thread 1"5/8 - 12 UNF)	
<b>C S07</b>		Central outlet (thread SAE 3000 - 1"1/4 MA)	
<b>C S08</b>		Central outlet (thread SAE 3000 - 1"1/4 UNC)	
<b>F G07</b>		Lateral outlet (thread G 1"1/4)	
<b>F U07</b>		Lateral outlet (thread 1"5/8 - 12 UNF)	
<b>G G07</b>		<b>only for TK</b>	
<b>G U07</b>			Front outlet side A (thread G 1"1/4)
<b>G S07</b>			Front outlet side A (thread 1"5/8 - 12 UNF)
<b>G S08</b>			Front outlet side A (thread SAE 3000 - 1"1/4 MA)
<b>H G07</b>		<b>only for TJ</b>	
<b>H U07</b>			Rear outlet side B (thread G 1"1/4)
<b>H S07</b>			Rear outlet side B (thread 1"5/8 - 12 UNF)
<b>H S08</b>			Rear outlet side B (thread SAE 3000 - 1"1/4 MA)
			Rear outlet side B (thread SAE 3000 - 1"1/4 UNC)




Outlet with two tanks classification

outlet identification


TM

Outlet section with two return (T-HPCO)  
right-side inlet (P)



TN

Outlet section with two return (T-HPCO)  
left-side inlet (P)




outlet combination and thread available

<b>M G07</b>		<b>only for TM</b>	HPCO Upper outlet T rear outlet side B (thread G 1 1/4)	<b>Q G07</b>		<b>only for TN</b>	HPCO Central outlet T front outlet side A (thread G 1 1/4)
<b>M U07</b>			HPCO Upper outlet T rear outlet side B (thread 1 5/8-12 UNF)	<b>Q U07</b>			HPCO Central outlet T front outlet side A (thread 1 5/8-12 UNF)
<b>M S07</b>			HPCO Upper outlet T rear outlet side B (thread SAE 3000 3/4 MA)	<b>Q S07</b>			HPCO Central outlet T front outlet side A (thread SAE 3000 3/4 MA)
<b>M S08</b>			HPCO Upper outlet T rear outlet side B (thread SAE 3000 3/4 UNC)	<b>Q S08</b>			HPCO Central outlet T front outlet side A (thread SAE 3000 3/4 UNC)
<b>M S35</b>			HPCO Upper outlet T rear outlet side B (thread SAE 6000 1" MA)	<b>Q S35</b>			HPCO Central outlet T front outlet side A (thread SAE 6000 1" MA)
<b>M S36</b>			HPCO Upper outlet T rear outlet side B (thread SAE 6000 1" UNC)	<b>Q S36</b>			HPCO Central outlet T front outlet side A (thread SAE 6000 1" UNC)
<b>N G07</b>		<b>only for TN</b>	HPCO Upper outlet T front outlet side A (thread G 1 1/4)	<b>R G07</b>		<b>only for TM</b>	HPCO Upper outlet T rear outlet side B (thread G 1 1/4)
<b>N U07</b>			HPCO Upper outlet T front outlet side A (thread 1 5/8-12 UNF)				HPCO Upper outlet T rear outlet side B (thread 1 5/8-12 UNF)
<b>N S07</b>			HPCO Upper outlet T front outlet side A (thread SAE 3000 3/4 MA)				HPCO Upper outlet T rear outlet side B (thread SAE 3000 3/4 MA)
<b>N S08</b>			HPCO Upper outlet T front outlet side A (thread SAE 3000 3/4 UNC)				HPCO Upper outlet T rear outlet side B (thread SAE 3000 3/4 UNC)
<b>N S35</b>			HPCO Upper outlet T front outlet side A (thread SAE 6000 1" MA)				HPCO Upper outlet T rear outlet side B (thread 1 5/8-12 UNF)
<b>N S36</b>			HPCO Upper outlet T front outlet side A (thread SAE 6000 1" UNC)				HPCO Upper outlet T rear outlet side B (thread 1 5/8-12 UNF)
<b>P G07</b>		<b>only for TM</b>	HPCO Central outlet T rear outlet side B (thread G 1 1/4)	<b>S G07</b>		<b>only for TN</b>	HPCO Upper outlet T side outlet A (thread G 1 1/4)
<b>P U07</b>			HPCO Central outlet T rear outlet side B (thread 1 5/8-12 UNF)				HPCO Central outlet T rear outlet side B (thread 1 5/8-12 UNF)
<b>P S07</b>			HPCO Central outlet T rear outlet side B (thread SAE 3000 3/4 MA)				HPCO Central outlet T rear outlet side B (thread SAE 3000 3/4 MA)
<b>P S08</b>			HPCO Central outlet T rear outlet side B (thread SAE 3000 3/4 UNC)				HPCO Central outlet T rear outlet side B (thread SAE 3000 3/4 UNC)
<b>P S35</b>			HPCO Central outlet T rear outlet side B (thread SAE 6000 1" MA)				HPCO Central outlet T side outlet A (thread 1 5/8-12 UNF)
<b>P S36</b>			HPCO Central outlet T rear outlet side B (thread SAE 6000 1" UNC)				HPCO Central outlet T side outlet A (thread 1 5/8-12 UNF)




**CARRY-OVER CONNECTION (HPCO)**

This option, available on all D20, allows the sectional valve to feed a second valve, by extending the free flow channel. In this configuration, the valve need a separated port for connection to tank.




It is possible to transform sectional valve from standard to HPCO version just by ordering the appropriate conic plug:



code (HPCO Plug identification)	description	q.ty
413010201	conic plug G 1/2 x 17	1




D20 SPARE PARTS LIST



Ref.	Description	Order code	Q.ty	Code	Note
		<b>30168</b>			Setting: 100 bar
	Pilot operated pressure relief valve (*)	<b>3143</b>	1		Setting: 200 bar
		<b>4383</b>			Setting: 300 bar
<b>1</b>	Relief valve plugged	<b>430109001</b>	1	-	
	Main Anticavitation check valve	<b>915050901</b>	1		
	External piloted valve	<b>915040901</b>	1		
	Plug with pressure-gauge connection	<b>430109003</b>	1		
		<b>421208010</b>		<b>W001A</b>	
	3 positions double-acting spool	<b>421208022</b>	1	<b>W001B</b>	
		<b>421208001</b>		<b>W001A</b>	for hydraulic actuation
		<b>421208005</b>		<b>W002A</b>	
<b>2</b>	3 positions double-acting A and B to tank spool	<b>421208002</b>	1	<b>W002B</b>	
		<b>421208023</b>		<b>W002A</b>	for hydraulic actuation
	3 positions single-acting on A	<b>421208015</b>	1	<b>W005A</b>	
	3 positions single-acting on B	<b>421208017</b>	1	<b>W006A</b>	
	4 positions double-acting with float in the 4 <sup>th</sup> pos.	<b>421208012</b>	1	<b>W012A</b>	
		<b>421208011</b>			for hydraulic actuation
		<b>320308002</b>			
<b>3*</b>	Control without lever	<b>320308005</b>	1	<b>H004</b>	only for W012 spool
	Protected vertical safety lever	<b>320308001</b>	1	<b>H101 = H102</b>	
		<b>320308003</b>			only for W012 spool
		<b>320508001</b>	2		for BSP version
<b>3</b>	Hydraulic actuation with side ports	<b>320508005</b>	1	<b>H005</b>	only for W012 spool - for BSP version
		<b>320508023</b>	2		for UNF version
		<b>320508024</b>	1		only for W012 spool - for UNF version



Ref.	Description	Order code	Q.ty	Code	Note
<b>4*</b>	3 position spring centred spool	<b>320708001</b>	1	<b>F001A</b>	
	Detent in A and B	<b>320808001</b>	1	<b>F002A</b>	
	Detent in A	<b>320808002</b>	1	<b>F003A</b>	
	Detent in B	<b>320808003</b>	1	<b>F004A</b>	
	Detent in 4 <sup>th</sup> position	<b>320808004</b>	1	<b>F005A</b>	only for W012 spool
	Prearrangement dual command	<b>320708005</b>	1	<b>F013A</b>	
	Pneumatic control ON-OFF	<b>321108003</b>	1	<b>F020A=F021A</b>	BSP ports
	Proportional Pneumatic control	<b>321208002</b>	1	<b>F022A=F023A</b>	BSP ports
		<b>321208004</b>	1	<b>F126A=F127A</b>	NPT ports
	Electrohydraulic ON-OFF (12 vdc)	<b>321408021</b>	1	<b>F1600</b>	
	Electrohydraulic ON-OFF (24 vdc)	<b>321408022</b>	1	<b>F1610</b>	
	Electrohydraulic Proportional (12 vdc)	<b>322008001</b>	1	<b>F2600</b>	
	Electrohydraulic Proportional (24 vdc)	<b>322008002</b>	1	<b>F2610</b>	
	Electrohydraulic ON-OFF (12 vdc) with reducing valve	<b>321408023</b>	1	<b>F1500=F1520</b>	BSP ports
	Electrohydraulic ON-OFF (24 vdc) with reducing valve	<b>321408024</b>	1	<b>F1510=F1530</b>	BSP ports
	Electrohydraulic Proportional (12 vdc) with reducing valve	<b>322008003</b>	1	<b>F2500=F2520</b>	BSP ports
	Electrohydraulic Proportional (24 vdc) with reducing valve	<b>322008004</b>	1	<b>F2510=F2530</b>	BSP ports
Electrohydraulic ON-OFF (12 vdc) with reducing valve	<b>321408025</b>	1	<b>F1500=F1520</b>	UNF ports	
Electrohydraulic ON-OFF (24 vdc) with reducing valve	<b>321408025</b>	1	<b>F1510=F1530</b>	UNF ports	
Electrohydraulic Proportional (12 vdc) with reducing valve	<b>322008005</b>	1	<b>F2500=F2520</b>	UNF ports	
Electrohydraulic Proportional (24 vdc) with reducing valve	<b>322008006</b>	1	<b>F2510=F2530</b>	UNF ports	
<b>5</b> Check valve on the work section	<b>320208001</b>	1	-	only for RP and RT section	
<b>6</b>	Antishock valve on port A	<b>3027</b>			Setting: 100 bar
		<b>2647</b>		<b>01 PA</b>	Setting: 200 bar
		<b>2781</b>			Setting: 300 bar
	Anticavitation valve on port A	<b>915080801</b>	1	<b>02 PA</b>	
	Pilot combined valve on port A	<b>15888</b>			Setting: 100 bar
<b>5091</b>			<b>04 PA</b>	Setting: 200 bar	
	<b>8943</b>			Setting: 300 bar	
Prearrangement for auxiliary valve on port A	<b>430409001</b>		<b>05 PP</b>		
<b>7</b>	Antishock valve on port B	<b>3027</b>			Setting: 100 bar
		<b>2647</b>		<b>01 PB</b>	Setting: 200 bar
		<b>2781</b>			Setting: 300 bar
	Anticavitation valve on port B	<b>915080801</b>	1	<b>02 PB</b>	
		<b>15888</b>			Setting: 100 bar
	Pilot combined valve on port B	<b>5091</b>		<b>04 PB</b>	Setting: 200 bar
		<b>8943</b>			Setting: 300 bar
Prearrangement for auxiliary valve on port B	<b>430409001</b>		<b>05 PB</b>		
<b>8</b>	Plug kit (G 1)	<b>430000021</b>		<b>G06</b>	
	Plug kit (G 1"1/4)	<b>430000022</b>		<b>G07</b>	
	Plug kit (1"5/16-12 UNF)	<b>300008002</b>	1	<b>U06</b>	
	Plug kit (1"5/8-12 UNF)	<b>300009002</b>		<b>U07</b>	



Inlet and work section			
Rif.	Order code	Description	Q.ty
1	423401017	Ring	4
2	412020603	O.R. 90SH (2-129)	4
<b>Complete Gasket kit: order code - 350909001</b>			





**INSTALLATION AND MAINTENANCE**

**Guidelines**


- Mount the control valve securely to a flat surface (recommended 3 point fixing); at the time do not use a hammer to positioning by hitting.
- When handling the control valve, be careful not hold the pilot cover or return spring cap of the spool or accessory valves such as main relief valves and anti-shock relief valves.
- Clean piping materials sufficiently before use.
- Make sure to prevent the port openings from being entered with dust or foreign matters.
- Tighten the port connectors surely with the recommended fastening torques.
- Do not direct the jet of a pressure washing unit directly to the valve.

**Fittings tightening torque (Nm)**

thread type	port P	Port A - B	Port T
<b>BSP (ISO - 228)</b>	<b>G 1</b>	<b>G 1</b>	<b>G 1</b>
with rubber sealing (DIN 3869)	120	120	120
with copper or steel and rubber washer	120	120	120
<b>BSP (ISO - 228)</b>	<b>G 1 1/4</b>	<b>G 1 1/4</b>	<b>G 1 1/4</b>
with rubber sealing (DIN 3869)	120	120	120
with copper or steel and rubber washer	120	120	120
<b>UN-UNF (ISO - 725)</b>	<b>1 1/16 12 UNF</b>	<b>1 1/16 12 UNF</b>	<b>1 1/16 12 UNF</b>
with O.R.	120	120	120
<b>UN-UNF (ISO - 725)</b>	<b>1 5/16 12 UNF</b>	<b>1 5/16 12 UNF</b>	<b>1 5/16 12 UNF</b>
with O.R.	120	120	120

**General clamping torque**

The following table provides the main tightening torques of the distributor D20:





**Dimensions - Thread codes**

The connection ports size is indicated by an ordering code common for all Hydrocontrol products. Following table shows all available connections.

**METRIC THREAD (ISO 9974-1)**

Type	M18x1,5	M22x1,5	M27x2
Code	<b>M01</b>	<b>M02</b>	<b>M03</b>


**BSP THREAD (ISO 1179-1)**

Type	1/4"	3/8"	1/2"	3/4"	1"	1"1/4	1"1/2	2"
Code	<b>G02</b>	<b>G03</b>	<b>G04</b>	<b>G05</b>	<b>G06</b>	<b>G07</b>	<b>G08</b>	<b>G09</b>

**UN / UNF THREAD (ISO 11926-1)**

Type	9/16" 18 UNF SAE6	3/4" 16 UNF SAE8	7/8" 14 UNF SAE10	1"1/16 12 UNF SAE12	1"5/16 12 UNF SAE16	1"5/8 12 UNF SAE20
Code	<b>U02</b>	<b>U03</b>	<b>U04</b>	<b>U05</b>	<b>U06</b>	<b>U07</b>

**Dimensions - SAE Flange codes**



**SAE / 3000 FLANGE (ISO 6162-1)**

Type	3/4" (MA)	3/4" (UNC)	1" (MA)	1" (UNC)	1"1/4 (MA)	1"1/4 (UNC)	1"1/2 (MA)	1"1/2 (UNC)	2" (MA)	2" (UNC)	3" (MA)	3" (UNC)
Code	<b>S03</b>	<b>S04</b>	<b>S05</b>	<b>S06</b>	<b>S07</b>	<b>S08</b>	<b>S09</b>	<b>S10</b>	<b>S11</b>	<b>S12</b>	<b>S15</b>	<b>S16</b>
A	19	19	25	25	32	32	38	38	51	51	76	76
B	47,6	47,6	52,4	52,4	58,7	58,7	69,9	69,9	77,8	77,8	106,4	106,4
C	22,3	22,3	26,2	26,2	30,2	30,2	35,7	35,7	42,9	42,9	61,9	61,9
D	M10	3/8-16	M10	3/8-16	M10	7/16-14	M12	1/2-13	M12	1/2-13	M16	5/8-11

**SAE / 6000 FLANGE (ISO 6162-2)**

Type	3/4" (MA)	3/4" (UNC)	1" (MA)	1" (UNC)	1"1/4 (MA)	1"1/4 (UNC)	1"1/2 (MA)	1"1/2 (UNC)
Code	<b>S33</b>	<b>S34</b>	<b>S35</b>	<b>S36</b>	<b>S37</b>	<b>S38</b>	<b>S39</b>	<b>S40</b>
A	19	19	25	25	32	32	38	38
B	50,8	50,8	57,2	57,2	66,6	66,6	79,3	79,3
C	23,8	23,8	27,8	27,8	31,8	31,8	36,5	36,5
D	M10	3/8-16	M12	7/16-14	M14	1/2-13	M16	5/8-11



## GENERAL CONDITIONS AND PATENTS

### Introduction

These general conditions apply to all general supplies from Hydrocontrol s.p.a., after receiving orders from the Customer. Should commercial terms such as EXW, DDP, etc be mentioned, of course the Incoterms of the International Chamber of Commerce must be referred to, according to the test existing when the general supply conditions are agreed on.

### Management of orders

No Customer's order is binding to Hydrocontrol s.p.a. if Hydrocontrol s.p.a. has not confirmed the order in writing. Hydrocontrol s.p.a. commits to supplying the orders in compliance with the order confirmation that has been issued. Any disagreement with the content of the order confirmation must be communicated in writing to Hydrocontrol s.p.a. within and no later than 5 days from the delivery of the order confirmation. The Customer commits to paying for the goods supplied by Hydrocontrol s.p.a., according to the prices indicated on the order confirmation.

### Payment conditions

The Parties agree on the payment terms at the beginning of the supply. The terms will be indicated on the order confirmation. Should the Customer be late with the payments, Hydrocontrol S.p.a. will be entitled to require the payment of interests on arrears based on the exiting Prime Rate increased by 2%. Should there be any payment delay, Hydrocontrol s.p.a. will be entitled not to process the Customer's purchase order, even if it has already been confirmed.

### Delivery and shipment

The goods are always supplied Ex Works, even when Hydrocontrol s.p.a. agrees with the Customer that the shipment, or a part of it, will be arranged by Hydrocontrol s.p.a. It is agreed that the Customer will bear the risk of goods deterioration or damaging from the moment the goods are handed by Hydrocontrol s.p.a. to the first carrier.

### Product characteristics

Hydrocontrol s.p.a. commits to supplying good quality products, compliant with the technical specifications declared on the technical tables and on the catalogue. Hydrocontrol s.p.a, even without notice, at its own discretion, reserves the right to modify the products as necessary, without these changes altering the main characteristics of the products.

### Claims

Any claims about defects on delivered products (just as an example: claims about the packaging, the number, the quantity or the external product characteristics) will have to be notified to Hydrocontrol s.p.a. in writing, within and no later than 7 days from reception of the goods, otherwise the claims will be considered as null and void. Occult defects (the defects of the goods that cannot be spotted with a careful control of the goods received by the Customer), will have to be notified in writing to Hydrocontrol s.p.a. within 7 days from the discovery of the defect, and anyhow no later than 12 months from the delivery of the goods, otherwise the claim will be considered as null and void. Even in case of claim or objection, the Customer will never be entitled to suspend or delay the payments to Hydrocontrol s.p.a. for the products subject to claim or objection nor for any other supply.



**GENERAL CONDITIONS AND PATENTS**

**Warranty**

Should the products supplied by Hydrocontrol not be compliant or have the required quality and should this defect be due to Hydrocontrol, Hydrocontrol s.p.a. commits, at its choice, to replace or repair the faulty products, as long as the defect or lack of compliance is notified to Hydrocontrol s.p.a. in writing, as specified at point 6, within and no later than 18 months from product delivery. On the products that have been fixed or replaced in accordance with what specified above, the above-mentioned warranty applies. The 12 month duration starts from the date of repair or replacement. In case of defects, lack of quality or in case of lack of compliance for the supplied products, with the exception of fraud or serious offence, Hydrocontrol s.p.a. only commits to repairing or replacing the faulty products, according to what specified above. This warranty replaces any other Supplier's warranty or liability established by the law. This warranty excludes any other liability contractual or extra-contractual by Hydrocontrol s.p.a. on the products supplied by Hydrocontrol (as a mere example: damage refund, loss of profit, product recall campaign, etc). Hydrocontrol s.p.a. has signed a product civil liability police, with a suitable maximum coverage.

**Ownership retention**

The products supplied by Hydrocontrol s.p.a. will be owned by the latter until Hydrocontrol receives the complete payment for the supplied goods.

**Obligation confidentiality**

Hydrocontrol s.p.a. commits to not disclosing the technical and commercial information it receives from the Customer, unless this information has already been publicly disclosed.

**Patents**

The Customer is not allowed to use the provided Products, or a part of them, their descriptions or drawings protected or not protected by Patent or registered trademark in order to design or make similar products, unless Hydrocontrol s.p.a. previously issues its written authorization. Should Hydrocontrol s.p.a. give its written authorization, all patents, trademarks, registered designs, copyrights and intellectual property rights related or connected to the Products provided by Hydrocontrol s.p.a. will stay Hydrocontrol's property. The Customer commits to respecting the highest confidentiality.

**Applicable law and court of jurisdiction**

Hydrocontrol s.p.a.'s supplies are regulated by these General Supply Conditions and, for anything not defined here, by the Italian law. Any controversy related, generated or connected to the supply of Products by Hydrocontrol s.p.a., where Hydrocontrol s.p.a. is involved, will be exclusively dealt with by the Court of Bologna.







Walvoil worldwide

**WALVOIL S.P.A.**

DIREZIONE E COORDINAMENTO INTERPUMP GROUP S.P.A.  
Headquarters, Subsidiaries and Representative Offices

**Walvoil S.p.A. Headquarters**

Via Adige, 13/D . 42124 Reggio Emilia . Italy  
TEL. +39 0522 932411  
info@walvoil.com | www.walvoil.com

AUSTRALASIA

**Walvoil Fluid Power Australasia Pty Ltd**

13 Vanessa Way . Delahey VIC 3037 . Melbourne . Australia  
TEL. +61 458 918 750  
australasia@walvoil.com

BRAZIL

**Interpump Hydraulics Brasil Ltda | Walvoil Division**

Rua Gilberto de Zorzi, 525 . Bairro Forqueta 95115-730  
Caxias do Sul (RS)  
TEL. +55 54 3289 7000  
infobrasil@walvoil.com

CANADA

**Walvoil Canada Inc.**

3100, Rue Jacob Jordan . Terrebonne . Qc J6X 4J6 . Canada  
TEL. +1 450 477 1076 Ext:225  
info@walvoilcanada.com | www.walvoilcanada.com

CHINA

**Walvoil Fluid Power (Dongguan) Co. Ltd**

1st Floor, the Third Factory Area, Sijia, Shijie Town, Dongguan City  
Guangdong province. China.  
TEL. +86 769 81816189-8020  
info@walvoil.com.cn | www.walvoil.com.cn

SOUTH KOREA

**Walvoil Fluid Power Korea Ltd.**

(17818)80-15, Oseongsandan 1Ro, Oseong-myun, Pyeongtaek-si Gyeonggi-do  
Republic of Korea 451-872  
TEL. +82 31 682 6030  
info@walvoil.co.kr | www.walvoil.co.kr

FRANCE

**Walvoil Fluid Power France**

362 rue de Bretagne . Vritz . 44540 Vallons-de-l'Erdre  
TEL. +33 2 41 94 41 06  
france@walvoil.com

INDIA

**Walvoil Fluid Power (India) PVT. LTD.**

No. 1, 2nd Cross, 2nd Main, KIADB Industrial Area, Attibele, Anekal Taluk  
Bangalore - 562107 .  
TEL. +91 80 0614 24000  
info@walvoil.co.in | www.walvoil.co.in

U.S.A.

**Walvoil Fluid Power Corp.**

4111 North Garnett Tulsa, OK 74116, USA  
TEL. +1 918 858 7100  
info@walvoilusa.com | www.walvoilusa.com

**Walvoil Fluid Power Corp | Hydrocontrol Business Unit**

1109, Technology Drive . Red Wing . MN 55066 . U.S.A.  
TEL. +1 651 212 6400  
info@walvoilusa.com | www.walvoilusa.com

