

PUSH-BUTTONS ASSIGNMENT

Button	Command
1	out1 + out16
2	out2 + out16
3	out3 + out16
4	out4 + out16
5	out5 + out16
6	out6 + out16
7	out15 + out16
8	out14 + out16

The Pocket control unit is powered automatically when a button is pushed

The Pocket turns off:

- automatically after 10 sec. if not used.

Each push-button commands the respective output and the DV output contemporaneously.


The DV output turns off with a 0.5 s. delay.


The Emergency Stop output is positive only when the Pocket control unit is ON.

A connector (gray) supplied with:

- 12 contacts (max 1 mm²)
- 8 sealing plugs (to close unused outputs)
- wedgelock

DTM Deutsch connectors





com.	Description
A1 A2	out16 (DV)
	out15 (P7)
A3	-Supply voltage
A4	out14 (P8)
A5	Emergency Stop
A6	+Supply voltage
A7	out1 (P1)
A8	out2 (P2)
A9	out3 (P3)
A10	out5 (P5)
A11	out4 (P4)
A12	out6 (P6)
B1	out7
B2	out8
В3	out9
B4	out10
B5	out11
В6	out12
B7	RS232 TX
В8	RS232 RX
В9	out13
B10	out17
B11	out18
B12	out19

Conn. Description

Supply voltage: 10 - 28V

Max current specifications:

- OUT1 to OUT19: 2,5 A
- The whole receiver must not exceed: 10 A
- Emergency stop output: 10A

SW: FC60003M

